


Pedometer Use Instructions.

Aussie Fit Sport Science

GEN-3 *SLIMLINE* multi-function model



FEATURES

1. Larger easy-to-read display
2. Flips down for easy viewing while on waist
3. Auto scan function
4. Auto power ON/OFF
- **Auto Filter Sensor:**
5 steps movement sensor filters out irregular results and activates only after 5 or more steps.
- **Delayed Reset Button:**
This is to prevent accidentally erasing the records on the display.
- **Accurate Pendulum Movement:**
The pedometer is controlled by an internal pendulum that moves down with each step that you take and springs up again.

FUNCTIONS

1. Records number of steps taken to 199,999 steps.
2. Measures distance traveled to 999.99 Kilometers or Miles.
3. Calculates CAL burned.
4. Shows time used during current walk/run up to 100 hours.
5. Display time in hours (AM and PM) and minutes format.

TO OPEN THE PEDOMETER

1. To open the lid is to monitor the records you exercised.
2. To work properly, pedometer case must be closed.

TO SET THE MEASUREMENT

1. Decide first if you want to work in Kilometers or Miles.
2. Hold the RESET button (E) for 5 seconds to convert the displayed value from Imperial to Metric unit or vice versa.
3. The originally displayed value will reset to zero.

TO SET YOUR STRIDE (30-215cm or 1-7ft)

1. Walk or run a measured distance and divide by the number of steps traveled to arrive at your stride length.
2. Press the MODE button (C) to move the cursor to point "DIST".
3. Press the SET button (D) and display shows previous stride length.
4. Each repeated press of the SET button increases stride by 1cm (0.05ft).
5. Press the RESET button (E) to decrease your stride length.
6. When personal stride is complete, the display will return to original display after 3 seconds.

TO SET YOUR WEIGHT (30-135kg or 60-300lb)

1. Press the MODE button (C) to move the cursor to point "CAL".
2. Press the SET button (D) and display shows previous weight.
3. Each repeated press of the SET button increases weight by 1kg (1lb).
4. Press the RESET button (E) to decrease your weight.
5. When personal weight is complete, the display will return to original display after 3 seconds.

TO SET THE CLOCK

1. Press the MODE button (C) to move the cursor to the point of clock icon "⌚".
2. Press the SET button to show time to be adjusted.
3. Press the RESET button (E) to adjust "HOUR" digit.
4. Press the SET button (D) to adjust "MINUTE" digit.
5. When the clock is set, the display will return to original display after 3 seconds.

TO OPERATE THE PEDOMETER

1. Press the reset button for 2 seconds to reset all recorded data.
2. Start walking or running. The unit will keep track of your step, distance, calories burned, exercise timer and display time of day.

TO RESET THE PEDOMETER

1. Press the reset button for 2 seconds to clear memory of all recorded information and reset to zero.
2. Stride length and weight as set will not be affected.

TO RECALL TIME OF DAY

1. Press and hold the ⌚ button (A) to momentarily recall current time of day.
2. Release the ⌚ button to return to original display.

TO USE THE SCAN FEATURE

1. Press the SCAN button (B) to turn scanning on and the display will show **SCAN** indicator.
2. This views all five exercise readings in continuous cycle lasting 3 seconds.
3. Press the SCAN button again to stop cycling.

AUTO POWER ON/OFF


1. The display will blank when no activity has been detected for 4 minutes.
2. Press button or walk 5 steps to power ON the unit.

AUTO MOVEMENT SENSOR

1. To filter out random movements, the unit remains in standby mode until five (5) continuous steps are registered. Only then are the 5 steps calculated in, and an Active indicator "▲" appears on the upper left of display.
2. When regular walk/run movement stops, after 2 seconds the timer pauses and the unit switches to standby status (Active indicator "▲" disappears).

TO POSITION THE PEDOMETER

1. Clip the unit to your belt or to the top of your shorts, trousers or slacks as close to your hip as possible.
2. The unit is vertical to the ground as this will aid in proper function and make the display easy to read.



BATTERY REPLACEMENT

1. Insert a coin and open the unit lid on the bottom of the body.
2. Remove and replace battery with Maxell LR43 or equivalent.
3. Make sure that the "+" side is up.
4. Pedometer is not waterproof. Keep away from any liquid.
5. Treat it carefully. Do not drop it or expose it to shock.

Aussie Fit Sport Science Fair Dinkum Warranty

We are so confident in our pedometer quality we offer a three year warranty from the date of purchase against any manufacturer defect when used as instructed for its designed purpose. The battery will last over one year and is easily self replaced or by a battery kiosk or watchmaker. The pedometer is not waterproof, however we understand accidents can occur and pedometer damage may result. As a "fair dinkum" Aussie Company we offer to replace your pedometer at 50% of the purchase price should you accidentally damage it. Simply send your damaged pedometer with a covering note and 50% of the purchase price plus \$10.00 postage and handling fee to:

Aussie Fit Sport Science
3 Vantage Point Drive
Burleigh Heads Qld 4220
Australia
Ph/Fax (07) 5576 3688
Email sales@aussiefitsport.com.au
www.aussiefitsport.com.au

Please note this warranty offer is only available directly through Aussie Fit Sport Science Pty Ltd